

CARE & CLEANING GUIDE

Issued date: 3rd April 2019

Care Guide:

Airborne dust, dirt, and impurities can accumulate over time in the mesh causing visual defects to your MESHTEC doors and screens. In order to prevent this, and ensure enduring quality and extended product lifespan, we recommend the following care be taken with all MESHTEC™ products: regularly clean your MESHTEC™ screen doors and screens every month;

- Wash down the mesh and frame using a soft cloth, mild soap or detergent and water, taking care to remove any excess moisture or water when done;
- Avoid using any sharp objects or materials with your MESHTEC™ screens and doors to prevent visual defects;
- The recommended maintenance and cleaning intervals provided are for general guidance only. In areas of harsh environmental conditions such as beachfront or industrial areas cleaning should be done more regularly – up to once per week in areas where the screens and doors are exposed to salt- water or other highly corrosive agents.

Cleaning Guide for contamination:

Apparatus:

1. Soft cotton or Microfiber fabric



2. Soft brush



3. Car wash and Car wax, car polish



Car wash

Car polish

CARE & CLEANING GUIDE

Issued date: 3rd April 2019

Cleaning procedure:

Step 1: Clean by car wash


Step 2: Wipe by soft cotton or microfiber fabric and waiting for dry

Step 3: Use soft brush to clean with car wax or car polish

Caution: Do not use strong solvents such as thinner, strong acids or strong bases polishing to clean because the color of the stain or even disintegration.

Cleaning result:

BEFORE CLEAN
Present contamination



AFTER CLEAN
No contamination

